



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 5-18-21

Model 2020+RT-FBR

2020+RT FLOOR BOARD RISER KITS

Steps needed to install your Floorboard Risers.



- 1.- Raise the RT off the ground to get to the 3 bolts that secure Floorboard to the frame. Remove these 3 bolts. These are circled in red below. Do this for each side.



2.- Once removed take the new riser blocks as shown and mount them to the frame. These risers allow the Floorboard to be mounted in 1" increments of rise for a total of 2". Decide on which height fits you best. Notice the flat side should be on the outside.



3.- Next take the supplied new bolts and washers and reinstall the Floorboards in the top holes of the new riser blocks. Use **Blue Loctite** on all bolts. Tighten down all 3 evenly. Do this for the other side as well.



Your new RT Floorboard risers are now installed. Test the feel. If need be, readjust to another level for the most comfortable feel.

We thank you for purchasing our 2020+ RT Floorboard Riser Kit. Today we know the needs for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder®!