

INSTALLATION INSTRUCTIONS

Embark on Your Journey with Confidence.

These instructions are for both riders and dealers – written as a step-by-step guide with an eye for detail, just like our products. It's all part of your experience with Show Chrome, and we take that seriously.

Please review the instructions before diving in, and if things get uncomfortable, don't hesitate. Reach out to us. We're here to help and offer direct, human customer service based in Rice Lake, WI, USA – every time at 888-244-2453. Ride safely, and ride often.

Final Product:



Product: ADJUSTABLE HOOD ROD Part # 44-110					
INSTALLATION TIME: 5-10 MIN		Fitment: POLARIS SLINGSHOT 2015 +			
TOOLS NEEDED:	12MM WRENCH				
INCLUDED:	ADJUSTABLE HOOD ROD (1X)				

INSTRUCTIONS:

- 1. Let's start by opening the hood of the Slingshot.
- 2. Locate the stock OEM hood pin and the hood latches. See FIG. 1 to identify where the previously mentioned parts are in the Slingshot.
 - **NOTE:** The stock OEM hood pin and hood latches shown in **FIG.1** are the left side ones, there is also a hood pin and hood latches in the right side of the vehicle and the product can be installed in either side using these same instructions.
- 3. Use FIG. 2 to identify the parts of the Adjustable Hood Rod.
- 4. Slide on the ROUTING EYEBOLT END over the stock OEM hood pin as seen in FIG. 3.
- **5.** Push down slightly on the hood of the Slingshot, as if you were going to close the hood. Place the *HOOK ANCHOR END* of the Adjustable Hood Rod in the hood latches as seen in **FIG. 4**; put some weight in the product so the *HOOK ANCHOR END* gets locked in position on the hood latches.
- 6. Adjust height of the Adjustable Hood Rod, by using a 12mm wrench and loosen the nuts located at each end of the Adjustable Hood Rod, then simply thread center tube to desired position. Then tighten up nuts to lock center tube into position.

REMOVAL:

- 7. Support hood and release the tension from the hood latches by pushing down on the latch cable seen in FIG. 5.
- **8.** Move hood to the fully open position.
- **9.** Simply slide off the *ROUTING EYEBOLT END* from the stock OEM hood pin and you have completely removed the Adjustable Hood Rod.



