

Copyright © 2017 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. H40-306BK

SNAP IN ORGANIZER

11/17/2017

FITMENT: CAN-AM SPYDER F3 2015-NEWER, UNIVERSAL

TOOLS NEEDED:	DRILL	1/8" (3MM) DRILL BIT	MASKING TAPE	PENCIL	TAPE MEASURE
	PHILLIPS SCREWDRIVER	CLEAN TOWEL	RUBBING ALCOHOL	FLAT SCREWDRIVER	

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**

**ESTIMATED INSTALLATION TIME: 15 TO 20 MIN.**

### F3 SPYDER INSTALLATION:

1. OPEN THE FRONT TRUNK AND REMOVE THE SERVICE PANEL. SEE FIG. 1.
2. USING A FLAT SCREWDRIVER PRY UP THE CENTER OF THE FOUR PLASTIC RIVET AND REMOVE THE FRONT TRUNK. SEE FIG. 1.
3. PLACE THE TRUNK WITH THE BACK SIDE DOWN ON A FLAT SURFACE AND USING RUBBING ALCOHOL CLEAN THE AREA SHOWN IN FIG. 2. LET DRY.
4. PLACE THREE PIECES OF MASKING TAPE ON THE INSIDE BACK OF THE TRUNK AS SHOWN IN FIG. 3.
5. USING A TAPE MEASURE FIND THE CENTER OF TRUNK AND MARK A CENTER LINE AS SHOWN IN FIG. 3.
6. NEXT MARK LINES 5 INCHES FROM THE CENTER LINE EACH WAY. SEE FIG. 3.
7. MARK CROSS LINES 5 INCH'S UP FROM THE SMALL LEDGE AS SHOWN IN FIG. 3.
8. DRILL TWO 1/8" (3MM) HOLES AT THE MARKS THROUGH THE PLASTIC.
9. USING A PHILLIPS SCREWDRIVER INSTALL THE TWO SCREW SNAPS AS SHOWN IN FIG. 4.
10. ATTACH THE ORGANIZER TO THE TRUNK USING THE TWO SNAP.
11. LIFT UP THE BOTTOM OF THE ORGANIZER AND REMOVE THE FILM FROM THE TAPE ON THE BACK OF THE ORGANIZER.
12. FIRMLY PRESS THE ORGANIZER TO THE TRUNK TO ATTACH THE TAPE.
13. REINSTALL THE TRUNK AND THE SERVICE PANEL.

### UNIVERSAL INSTALLATION:

1. FIND A SURFACE TO MOUNT THE ORGANIZER TO AND CLEAN THE AREA WITH RUBBING ALCOHOL.
2. PUT TWO PIECES OF MASKING TAPE ON THE SURFACE WHERE THE SNAPS ARE GOING TO BE LOCATED.
3. MARK THE FIRST SNAP LOCATION WITH A "+" AND THEN MEASURE 10" FROM THERE FOR THE OTHER SNAP AND MARK IT.
4. **BEFORE DRILLING HOLES FOR THE SNAPS CHECK THE AREA BEHIND THE MOUNTING SURFACE TO MAKE SURE THE DRILL AND THE SCREWS WILL NOT INTERFERE WITH ANYTHING ELSE ON THE BIKE.**
5. USING A 1/8" (3MM) DRILL BIT DRILL TWO HOLES AT THE MARKS YOU MADE.
6. USING A PHILLIPS SCREWDRIVER INSTALL THE TWO SCREW SNAPS.
7. ATTACH THE ORGANIZER USING THE TWO SNAP.
8. LIFT UP THE BOTTOM OF THE ORGANIZER AND REMOVE THE FILM FROM THE TAPE ON THE BACK OF THE ORGANIZER.
9. FIRMLY PRESS THE ORGANIZER TO THE SURFACE TO ATTACH THE TAPE.

