



Nelson & Nelson Mfg.
2200 Fowler Ave, Suite D
Jonesboro AR 72401
870-268-6393 : Cell 219-1019

Installation Instructions 3-20-18

Model SF3RT-SBL

Spyder F3 & RT Sway Bar Lins

Steps needed to install your Sway Bar Links



See Authorized Dealers for installation if needed.

- 1.- Remove left & right side factory Sway Bar Links by removing two bolts on each link.
- 2.- Take the new Sway Bar Links with spacers and install the link upper end first. Be sure to place a spacer between the link and frame cradle mount each side. If having trouble installing spacers you may use super glue to temporarily hold the spacer in place as you raise the link into the cradle. Otherwise a pair of needle nose plyers will allow you to hold the spacer while inserting between the link and cradle as you run the existing factory bolt through the holes.
- 3.- The lower link connection is one factory bolt with a spacer on each side of the link as in the upper link bearing. Be sure to use medium strength Loctite on all bolts before tightening down.

We thank you for purchasing one of our F3 & RT Sway bar links. We know today the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder®!

spyderextras.com