



## Can Am Ryker 2 inch Pivoting risers



M6 Bolts to Replace OEM Bolts    Rox OEM Replacement caps    M8 Bolts to use in Rox Risers

- 1) Remove OEM caps and M6 bolts that are clamping the handlebars to your Ryker steering stem.
- 2) Set OEM caps/bolts aside. **DO NOT USE OEM CAPS or BOLTS with Rox Pivoting Risers.**
- 3) take your handlebars out of the clamp.
- 4) Replace the OEM handlebar clamps and OEM M6 bolts with the new Rox Billet Replacement handlebar clamp caps and new M6 bolts provided.
- 5) Install Rox Risers into the new Rox handlebar clamp caps, lightly snug bolts to hold the risers in place **making sure each cap gap is even and balanced.**
- 6) Install handlebars in Rox Risers and install caps on risers to hold bars. Lightly snug bolts
- 7) Sit on your machine and find your desired handlebar position. Once achieved evenly tighten all bolts, see torque specs below.
  - a. M8 bolt on top of riser torque spec is 18-20 foot pounds (228 in. lbs).
  - b. New M6 bolts In the Rox replacement handlebar clamps torqued to 13.5 foot lbs. (162 in/lbs.) **DO NOT OVERTIGHTEN!!**
  - b. Use Blue Loctite on all bolts
- 8) Once bolts are tight, turn bars left and right to make sure no cables and lines are binding.

See Full Install video at [Slingmods.com](http://Slingmods.com)