



## How to Install F3-Touring Brackets on the F4

Customs F3-T Replacement Windshield



### Parts List:

- 4 – Black powder coat brackets
- 8 – Aluminum spacers
- 4 – Black snap caps
- 4 – White snap cap washers
- 5 – 4mm bolts
- 5 – Serrated nuts

### Installation Instructions:

**\*\*\*\*Please Note this windshield does not fit with the Tall Boy mounting hardware\*\*\*\***

1. Remove the plastic wrapping around the 4 bolt holes. Leave the remaining plastic on the shield to ensure protection during the installation process.

2. Turn the shield so that the front of the windshield is facing down.

3. Take one mounting bracket and place it on the front of the shield, hold it in place while you take 4 of the aluminum spacers and drop them in the mounting holes.



4. Take 2 snap cap washers and 4mm bolts, place the bolt through the washer as pictured below.

5. Place one bracket on the backside of the shield.

6. Insert the two bolts with the snap caps through the top two holes on the front of the windshield so the threads of the bolts are up.



7. Take two serrated nuts and tighten them down over the two bolts.



8. To keep the brackets from moving, and to keep the aluminum washers in place use the extra 4mm bolt and nut in the bottom hole. (This will need to be removed before mounting.)



9. Place black snap caps over the front snap cap washers.
10. Repeat steps on the other side.
11. Remove the extra bolt and nut from the bottom holes and insert the OEM bolts (from your motorcycle) through the bottom four bolt holes.
12. Mount the windshield to the existing hardware.

Contact us with any questions  
941-347-7496  
[customerservice@f4customs.com](mailto:customerservice@f4customs.com)