



**Nelson & Nelson Mfg.**  
5210 Stadium Blvd. Suite C  
Jonesboro AR 72404  
870-268-6393 : Cell 219-1019

Installation Instructions 3-9-21  
**Model RYK-FLRB**

**Steps needed to install your Ryker Driver Floor Boards.**  
**DO NOT USE IMPACT DRILL ON BOLTS OR NUTS.**

(Stainless Steel Hardware is Softer Metal and can strip the threads.)

You must use lubricant on bolts and nuts to prevent galling. Minimum WD40, preferably Anti-Seize  
Stainless Steel Lubricant MRO 1000



**Complete Kit shown above. For all Ryker Models.**

1.- The New Spyder Extras Ryker Floorboard kit is simple to install and is the most comfortable floorboard option on the market. Set at an angle that fits the rider's position. This allows too the floorboard to be tilted up and adjusted as the normal foot peg allowed.

First drill two 5/16" holes on each oem highway peg as shown below in this exact position. This hole location lines up with the floorboard mount holes. Start with an 1/8" bit to drill a pilot hole.



2.- Take the two Socket Head Bolts and place the floorboard main support over the footrest and take the mount lock plate and mount it from the bottom as shown below. Screw the bolts down through the mount then the footrest into the mount lock plate. Tighten down then add the safety locknuts as shown below.



3.- Take the floorboard plate with the letter R facing outwards and the two button heads screws and screw the floorboard plate down. Do the same for the opposite side.  
Your Floorboards are now installed. These floorboards allow full adjustment of your existing OEM pegs.

**4.-Once Installed do not stand on the rear of the Floorboards. Stand over the peg location only!**



We thank you for purchasing one of our Ryker Accessory Kits. Today we know the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder!

[Spyderextras.com](http://Spyderextras.com)