

CENTER HOOD VENT FOR POLARIS SLINGSHOT

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

IMPORTANT

Your Center Hood Vent is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

KIT CONTENTS



ACCESSORY INSTALLATION

1. Open the original vehicle cover, unscrew the fixing screws on the back of the original center hood vent, and remove the original center hood vent.



2. Install the new center hood vent and fix it with the original screws.



3. Installation completed.

