## BIG BIKE PARTS® INSTALLATION INSTRUCTIONS Copyright® 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc. 9/21/2022 FITMENT: POLARIS SLINGSHOT 2015 - 2021

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

PHILLIPS BIT

ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

### INSTALLATION:

TOOLS NEEDED:

1. REMOVE THE PHILLIPS SCREW THAT HOLDS THE OEM SEAT LEVER IN PLACE.

¼" WRENCH

- 2. REMOVE OEM SEAT LEVER BY PULLING STRAIGHT AWAY FROM THE SEAT TO SLIDE OFF FROM THE SHAFT.
- 3. LINE UP NEW EXTENDED SEAT ADJUSTMENT LEVER WITH SPLINES IN DESIRED POSITION (ORIENTATION OF NEW EXTENDED SEAT ADJUSTMENT LEVER IS SUGGESTED TO BE HORIZONTAL BUT CAN BE ANGLED IF PREFFERED). NEW SPLINES WILL BE SNUG ON THE SHAFT SO SOME FORCE BY HAND MAY BE NEEDED. PUSH THE EXTENDED SEAT ADJUSTMENT LEVER ON TO SHAFT UNTIL THE LEVER DOES NOT GO ON ANY FURTHER.
- 4. LINE UP THE OEM PHILLIPS SCREW AND SLOWLY TURN BY HAND MAKING SURE NOT TO CROSSTHREAD THE SCREW. TIGHTEN THE SCREW UNTIL THE HEAD OF THE SCREW SITS MOSTLY RECESSED IN THE NEW LEVER AND IS TIGHT. (BE SURE NOT TO OVER TIGHTEN THE SCREW.)

## NOTICE

IGNORING THE CONTENTS OF THESE
INSTRUCTIONS MAY AFFECT THE PRODUCT
PERFORMANCE AND FUNCTIONALITY. NOT
FOLLOWING THESE INSTRUCTION MAY CAUSE
DAMAGE TO THE PRODUCT OR THE VEHICLE
TO WHICH IT IS BEING ATTACHED.

# BIG BIKE PARTS INSTALLATION INSTRUCTIONS Copyright® 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc. 9/21/2022 TOOLS NEEDED: PHILLIPS BIT INSTALLATION INSTRUCTIONS EXTENDED SEAT ADJUSTMENT LEVER FITMENT: POLARIS SLINGSHOT 2015 - 2021 W" WRENCH

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

**ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.** 

## INSTALLATION:

- 1. REMOVE THE PHILLIPS SCREW THAT HOLDS THE OEM SEAT LEVER IN PLACE.
- 2. REMOVE OEM SEAT LEVER BY PULLING STRAIGHT AWAY FROM THE SEAT TO SLIDE OFF FROM THE SHAFT.
- 3. LINE UP NEW EXTENDED SEAT ADJUSTMENT LEVER WITH SPLINES IN DESIRED POSITION (ORIENTATION OF NEW EXTENDED SEAT ADJUSTMENT LEVER IS SUGGESTED TO BE HORIZONTAL BUT CAN BE ANGLED IF PREFFERED). NEW SPLINES WILL BE SNUG ON THE SHAFT SO SOME FORCE BY HAND MAY BE NEEDED. PUSH THE EXTENDED SEAT ADJUSTMENT LEVER ON TO SHAFT UNTIL THE LEVER DOES NOT GO ON ANY FURTHER.
- 4. LINE UP THE OEM PHILLIPS SCREW AND SLOWLY TURN BY HAND MAKING SURE NOT TO CROSSTHREAD THE SCREW. TIGHTEN THE SCREW UNTIL THE HEAD OF THE SCREW SITS MOSTLY RECESSED IN THE NEW LEVER AND IS TIGHT. (BE SURE NOT TO OVER TIGHTEN THE SCREW.)

## NOTICE

IGNORING THE CONTENTS OF THESE
INSTRUCTIONS MAY AFFECT THE PRODUCT
PERFORMANCE AND FUNCTIONALITY. NOT
FOLLOWING THESE INSTRUCTION MAY CAUSE
DAMAGE TO THE PRODUCT OR THE VEHICLE
TO WHICH IT IS BEING ATTACHED.