

SIDE VIEW MIRROR COVER TRIM FOR POLARIS SLINGSHOT

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

IMPORTANT

Your Side View Mirror Cover Trim is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

KIT CONTENTS



ACCESSORY INSTALLATION

1. Open the original vehicle cover and wipe the surface of the original rear housing of the side view mirror. Remove the double-sided adhesive protective film on the back of the side view mirror cover trim.



2. Clip the side view mirror cover trim onto the side view mirror and press hard to make it fit better with the side view mirror.

Note: The wire harness on the side view mirror cover trim needs to be placed along the wire slot.



SIDE VIEW MIRROR COVER TRIM FOR POLARIS SLINGSHOT



3. Pull out the harness on the turn light of the original vehicle and connect it with the adapter wire configured for the side view mirror cover trim. Place the harness of the side view mirror cover trim along the vehicle harness to the place of the turn light (the harness can be fixed with ties), and then connect it with the adapter wire. (Install the other side mirror cover trim according to the same procedure).



4. Installation completed.

