



Nelson & Nelson Mfg.
2200 Fowler Ave, Suite D
Jonesboro AR 72401
870-268-6393 : Cell 219-1019

Installation Instructions

Model SF3-FB

Patent Pending

Spyder F3 Foot Rest Extensions

Steps needed to install your Foot Rest Road Pegs

1.- Remove the two screws under each foot rest on bottom side.
The Road Peg units a pre-assembled for the Floor Board Model.

2.-With the supplied new L-Bracket that supports the Road Peg Arm, install the bracket with the two new socket bolts. (See Step By Step Pictures below) Be sure to place the aluminum spacer between the bracket and press into hole the recessed holes in the bottom of the factory foot rest housing.

3.- You will see there are two holes for adjustment in the lower mounting bracket. The top hole is a typical location for the Road Peg. The lower hole allows more room for the foot to extend and you might find that more comfortable. Please try both to see what fits you best. Do the same for the Right side of the Spyder.

These Road Pegs are *Design to Compliment Your Spyder* as shown in the Adjustable Arm with the opening designs matching curves of the Spyder.



Left Side F3-T Road Peg Assembled on Floor Board

spyderextras.com



Bottom View of Left Floor Board



Bottom View of Left Floor Board w/ bolts installed



Bottom View of Left Floor Board, install Velcro on upper ledge as shown



Bottom View of Left Floor Board Rubber Pad, install Velcro on upper ledge as shown
Velcro will secure Rubber Pad to metal frame but allow access if needed



Bottom View of Left Floor Board, spacers & install bolts as shown



Bottom View of Left Floor Board Extension Installed
tighten all lock nuts securely

We thank you for purchasing one of our F3 Model Road Pegs. We know today the needs for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder®!

spyderextras.com