



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 2-22-22

Model SRT-2020+PFE

2020+ Spyder RT Passenger Floor Board Extenders

Steps needed to install your RT Passenger Rear Floor Board Extenders.



1.- First remove the passenger rear floorboards by removing the single bolt.



2.- Next as the photo above shows the left side of the RT take the left extender bracket and two of the black socket head bolts and washers supplied and install the bracket as shown below. You can adjust the bracket like the floorboard up or down. Once decided on the vertical position use **Blue Loctite on the bolts** and secure them in place.



3.- Next take the existing floorboard and mounting bolt and locate it in the bracket. The extender bracket allows a 2" or 4" forward extended position from the factory original position. This allows the passenger to stretch their legs for a more comfortable ride. Test the positions to see what best fits you as a rider. Secure this existing OEM bolt with **Blue Loctite**. Do the same for the opposite side and your extenders are now installed.



We thank you for purchasing our 2020+ RT Accessory Kits. Today we know the needs for accessories that provide a higher level of comfort & style while riding and we have solved that demand with a stylish system that compliments the design of your Spyder®!

spyderextras.com