


## Nelson & Nelson Mfg. 5210 Stadium Blvd, Suite C Jonesboro AR 72404 870-268-6393 : Cell 219-1019

Installation Instructions 1-26-23


## Model RYK-AWSM

Ryker Adjustable F4 Windshield Mount

## Steps needed to install your Ryker Adjustable F4 Windshield Mount



- 1.- This Ryker Windshield Adjustable mount is Designed to work between the F4 Ryker Shield and the Factory mount behind the handlebars. Follow the instructions on the F4 shield to remove the factory shield.
- 2.- On the F4 shield you will see a main mount bracket that mounts the shield to the Ryker. Take that mount as shown below using the screws, nuts and plastic caps and secure that mount to the main front adjustable mount as shown on the lower right photo below. This part of the mount fits inside the outer mount of the adjustable mount. Secure the lock nuts and install black cap covers.




3.- The adjustable mount comes complete with the necessary hardware. Take each knob and place a washer then aluminum guide spacer as shown below. Do this for all four knobs.



4.- Next take the outer mount of the kit and bolt it to the F4 large windshield mount as shown below. Use the suppled screws, plastic caps, and locknuts in the same way you installed the hardware on the inside mount unit.



5.-Once the two adjustable mount brackets are secured to the shield mount and the F4 Ryker mount you place them together with the two 3" aluminum spacer between as shown below that allows the mount to slide and tilt.



Do this for both 3" spacers using all 4 knobs. You will see that the outer mount bracket has a long slot that when installing the knobs, the spacer is the guide that fits in that slot allowing the two units to slide up and down.

6.- After installing the spacers the unit is ready to install on the Ryker. With the 4 suppled screws from F4. Install the bottom two first but do not tighten down. The tilt up and install the upper screws. Then tighten all equally.



Once installed on your Ryker, adjust the shield up or down to fit your riding needs. When hot outside you can tilt the shield towards you the rider and allow a greater airflow to keep cool. You can adjust the tilt to control the airflow.

Your Ryker adjustable F4 shield mount is now installed.