

PROGRAMMING ADDITIONAL REMOTES



To program a new chaser remote , locate the small black push button on the module.

With the unit plugged into the kit 1 or halo ring and 12V power, push the black button for 1 second and release, then push down again for 5 seconds until the lights start to flash RED color.

On the new remote press A, release. B, release, C release and D, release.

Now, test your new remote and it should be able to perform all the functions as your original remote.